

# SY-P293 PC to HDMI (1080p) Scaler

## **OPERATION MANUAL**





# Table of Contents

1.		Introduction	
2.		Features	1
3.		Package Contents	1
4.		Operation Controls and Functions	
	4.1	Front Panel Diagram	2
	4.2	Rear Panel Diagram	3
	4.3	Connection Diagram	4
5.		OSD Menu Reset	4
	5.1	OSD Menu Operations	5
	5.2	Supported Resolutions	6
6		Specifications	6



#### 1. Introduction

The SY-P293 is designed to upscale analogue video signal from a PC source to a digital HDMI output boosting a wide-range of HDTV and PC resolutions up to 1080p/WUXGA. The SY-P293 also converts inputted audio signal from Optical (Toslink) or analogue L/R to both digital and analogue audio outputs. Audio is then combined with HDMI video output audio simultaneously. The SY-P293 has a comprehensive OSD menu that allows the user to select a variety of output resolutions and adjust for best picture quality.

#### 2. Features

- v1.3 HDMI, HDCP 1.1 and DVI 1.0 compliant.
- Scales any PC resolutions to PC (VGA ~ WUXGA)/ HD (480i ~ 1080p) resolutions.
- Automatic detection of the factory setting of the connected display and output the corresponding resolution and refresh rate, when the NATIVE output is selected (default setting).
- Provides output picture adjustment on contrast, brightness, hue, saturation, sharpness, RGB (colour tone) level and aspect ratio size.
- Supports high resolution output (See section "6.2. Support Resolution" for reference):
  - PC: VGA, SVGA, XGA, SXGA, UXGA, WXGA, WSXGA, WUXGA.
  - SD/HD: 480i, 576i, 480p, 576p, 720p, 1080i and 1080p
- Supports stereo LPCM analogue/digital audio input and stereo LPCM analogue/digital output. Simply select from the audio input sources in the OSD menu, the audio is then outputted to HDMI, Optical (Toslink) and mini-jack simultaneously.


#### 3. Package Contents

- SY-P293
- 5V DC power supply adaptor.
- Operation Manual.



#### 4. Operation Controls and Functions


#### 4.1 Front Panel



- 1. PC Input: Connect the PC input D-Sub (15-pin) port to the D-Sub output port of your source equipment such as a PC.
- 2. Audio Input: Connect the PC 3.5mm stereo mini-jack input port to the analogue audio output port of your source equipment.
- 3. Optical (Toslink) Input: Connect the Optical input port to the Optical output port of your source equipment.
- 4. Power: Plug the 5VDC power supply into the unit and connect the adaptor to AC wall outlet.



#### 4.2 Rear Panel



- 1. HDMI Output: Connect the HDMI output port to the HDMI input port of your HDTV display.
- 2. Optical (Toslink) Output: Connect the optical output port to the Optical input port of your amplifier.
- 3. Audio Output: Connect the 3.5mm stereo mini-jack output port to the analogue audio input port of your equipment.
- 4. Menu Button: Press the MENU button to bring up OSD operation menu. (See section "4. OSD Operation" for reference.)
- 5. +/- Button: On the first tier of OSD menu, use + and buttons to move up/down the highlight item for selection.
  - Once the desired option is selected, use + and buttons to toggle between setting values.


Note: Outside of the OSD Menu, Press [-] Button to activate the Auto Adjust function. The screen will show Auto Adjust.

Press [MENU] and then [-] to switch to 480p mode.

Press [MENU] and then [+] to switch to XGA mode



#### 4.3 Connection Diagram



#### 5. OSD MENU Reset Fuction

To reset the unit, press and hold the MENU button then insert the DC power into the unit to set the unit back to factory default, with output resolution set to NATIVE. This feature is also useful when the output is scaled to a resolution not supported by the connected TV/monitor so no picture is shown, because the NATIVE resolution can guarantee to display.



#### 5.1 OSD Menu Operations

1 at Tier Onties	Ond Tipy Option	Adjustment		
1st Tier Option	2nd Tier Option	Adjustment		
CONTRAST	-	0 ~ 100 of Contrast Level		
BRIGHTNESS	-	0 ~ 100 of Brightness Level		
	- HUE	0 ~ 100 of Hue Level		
FINETUNE	- SATURATION	0 ~ 100 of Saturation Level		
TINLIONE	- SHARPNESS	0 ~ 100 of Sharpness Level		
	- EXIT	Back to 1st Tier		
	- RED	0 ~ 100 of Red Colour Level		
COLOR	- GREEN	0 ~ 100 of Green Colour Level		
COLOR	- BLUE	0 ~ 100 of Blue Colour Level		
	- EXIT	Back to 1st Tier		
SIZE	-	FULL / OVERSCAN / UNDERSCAN / LETTERBOX / PANSCAN		
OUTPUT	-	NATIVE / VGA / SVGA / XGA/ SXGA / UXGA / 480i / 480p/720p@60Hz / 1080i@60Hz / 1080i@50Hz / 576i / 576p / 720p@50Hz / 1080i@50Hz / 1080p@50Hz / WXGA / WSXGA / WUXGA		
AUDIO	-	EAR PHONE / OPTICAL		
	- HPOSITION	0 ~ 100 of OSD Horizontal Position		
	- VPOSITION	0 ~ 100 of OSD Vertical Position		
OSD	- TIMER	0 ~ 100 of OSD Existing Time (sec.)		
005	- BACKGROUND	0 ~ 100 of OSD Transparent Level		
	- EXIT	Back to 1st Tier		
INFORMATION	-	SOURCE (Input Interface) INPUT (Input Resolution) OUTPUT (Output Resolution) VERSION (Firmware Version)		
Mirror	ON/OFF			
EXIT	-	Close OSD Menu		

Note: Finetune function works differently under component and VGA input therefore, Hue, Saturation and Sharpness are only adjustable when the input signal is component.



#### 5.2 Supported Resolutions

Resolutions	PC INPUT	HDMI OUTPUT	
	PC	SD/HD	PC
480I/576I (NTSC/PAL)		V	
480P/576P		V	
720P@(50/60)		V	
1080(050/60)		V	
1080P@(50/60)		V	
VGA@(60/72/75/85)	V		V@60
SVGA@(56/60/72/75/85)	V		V@60
XGA@(60/70/75/85)	V		V@60
SXGA@(60/75/85)	V		V@60
UXGA@60	V		V
WXGA@60(1280x800)	V		V
WSXGA@60(1680x1050)	V		V
WUXGA@60(1920x1200)	V		V

Note:VGA/SVGA/XGA/SXGA/output only support@60Hz

### 6. Specifications

PC Input Port	x 1 VGA (15 PIN DSUB)		
HDCP Version	V1.1		
HDMI Output Port	1 X HDMI		
HDMI Specification	V 1.2		
Analogue Audio Input	3.5mm Stereo Jack		
Analogue Audio Output	3.5mm Stereo Jack		
Digital Audio Inputs	1 x Optical (Toslink)		
Digital Audio Outputs	1 x Optical (Toslink)		
Power Supply	5VDC/2.6A (US/EU standards, CE/FCC/UL Certified)		
Dimensions (mm)	154(D) x 100(W) x 25(H)		
Chassis Colour	Black		
Chassis Material	Aluminium		
Operating Temperature	Operating from 0°C ~ 48°C		
Weight (g)	340		



Notes:



www.cypeurope.com v1.01